## The QuickDeploy Key From the LeveLine Range

AQUAREAD

Revolutionise your water level monitoring by using the QuickDeploy Key and the LeveLine water level and temperature logger from Aquaread

Plug in - Initiate Logging - Check Levels - Deploy



Read

eveline

<sup>vick</sup>Deploy <sup>Ke</sup>

\*/s=

## Simplify your deployment and keep it flexible.

Set up the logging frequency and duration on the LeveLink PC software for all loggers in your next deployment and store them on the shelf until you're ready

## No Need to restrict yourself with a planned start date

Take the loggers into the field and initiate logging as you deploy with the added benefits of zeroing the depth sensor, checking memory and checking battery levels are both ok